

Maintenance

Timber is a natural material and the lifespan of our coatings will vary depending on the application, situation and installation.

Maintenance of Screenwood Ceiling and Wall Systems and Ceiling Panels varies according to the coating and the application.

Internal Coating

Where the Screenwood Ceiling Panels are used in an internal application and are pre-finished in internal grade coatings, periodic dusting should keep the panels looking their best. Should the panels require cleaning, we recommend wiping the panels down with a clean damp cloth. If the panels are subjected to any moisture, please wipe them down immediately. Internal coatings should not be wet down or hosed, as this will negatively impact the coating.

Oil coatings used in internal applications may be better cleaned with a soft brush and vacuum, taking care not to bruise the timber during this process.

External Coatings

Where the Screenwood Panels are used externally, the aspect of the façade can greatly influence the life as well as client expectations regarding the colour vibrancy of the coating.

To allow timber to weather naturally to grey/silver colour, a clear timber preservative treatment is suggested.

Oil Coating

Typically, oil finishes need to be reapplied every 12-24 months. When re-finishing is required simply wash down with detergent and water to remove dust and dirt and recoat to desired finish.



Should you require any further information, please contact us on:

Tel (02) 9521 7200 | Fax (02) 9521 7222

Email info@screenwood.com.au

Web www.screenwood.com.au

